

YANAK SOFT

НАСТРОЙКИ

SYMBOL LS2208



SET DEFAULTS



HID KEYBOARD EMULATION



SCAN OPTIONS



<DATA><SUFFIX>



STANDARD RS-232



ENTER



Enable NOTIS Editing



Enable Codabar

<http://yanaksoft.com/>